

1

**FOLD HERE** 

FOR INSTALLING DEADLOCKS

READ INSTRUCTIONS  
1 3/4" (45mm) THICK DOOR

2

MARK PROPER DOOR THICKNESS



3

DRILL 1" (25mm) HOLE IN EDGE OF DOOR (2" IN DEPTH)

1 3/8" 35mm THICK DOOR

**2 3/8" BACKSET** 

NOTE: TEMPLATE MUST BE PLACED ON HIGH EDGE OF DOOR BEVEL

4

MARK

2 3/8" (60mm)

BACKSET DISTANCE

2 1/4" (70mm)

5

DRILL 2" (50.8mm) HOLE

